


Panasonic TPA65

QUICK USER GUIDE

PLACING CALLS

Dial the phone number then pick up the receiver.

If the  icon is flashing, you may be out of range.
Move closer to the base unit and try dialing again.


ENDING CALLS

To end an active call, place the receiver back on the hook.

TRANSFERRING CALLS

You can transfer a call to another destination (extension or outside party).




To transfer:

- Press  (**TRANSFER**).
- Dial the number you want to transfer to and press **CALL**.
- Wait until the other party answers to announce the transfer.
- Place the receiver back on the hook.

FORWARDING CALLS

You can have incoming calls automatically forwarded to another destination. You can also have incoming calls rejected (Do Not Disturb).

To access the FWD/DND Settings:



- In Standby Mode, press  (**FUNC**), then press **2** (**FWD/DND**).
- Use the []/[] to select **FWD** and press **OK**.
- Once Call Forward is selected, enter a forward destination number.

TIP: Forwarding Calls

Enabling FWD (All) will cause all incoming calls to be forwarded.


PLACING CONFERENCE CALLS

To initiate a Conference Call:

- Press  (**FUNC**) during a conversation and select **Conference**.
- Dial the number of the party you want to add to the conversation.
- Press **CONF** / .



LISTENING TO VOICEMAIL

When you receive a voice message, **Voice MSG** will be displayed and the  icon will appear. You can check your new messages by accessing your mailbox.

In Standby Mode:

- Press the  button.
- Use the []/[] to select the line on which the  icon is displayed and press **OK**.