

Yealink IP DECT Phone W52/53P QUICK USER GUIDE

POWERING ON / OFF

To turn the handset on, do one of the following:

- Press , then the LCD screen lights up.
- Place the handset in the charger cradle. The handset will be turned on automatically.

To turn the handset off:

- Long press  to turn the handset off.

ANSWERING A CALL

To answer a call, do one of the following:

- Press the Accept soft key
- Press 
- Press 

Note: You can ignore an incoming call by pressing the Silence soft key or reject an incoming call by pressing .

ENDING A CALL

Press .

TRANSFERRING A CALL

Blind Transfer

1. Press the Options soft key during a call, and then select Transfer.
2. Enter the number you want to transfer the call to.
3. Press the Transfer soft key.

ADJUSTING THE CALL VOLUME

- Press  or  during a call to adjust the volume of the currently used audio device.
- Press  or  when the handset is idle to adjust the ringer volume.

ADJUSTING THE RING TONES

1. Press the OK key to enter the main menu, and then select **Settings->Audio->Ring Tones->Melodies**
2. Press  or  to highlight the Intercom Call option or the desired line.
3. Press  or  to select the desired ring tone.
4. Press the Save soft key to accept the change.

ADDING USERS TO PHONE BOOK

1. Press the OK key to enter the main menu, and then select Directory.
2. Press the Options soft key, and then select New Contact.
3. Enter the desired value in the Name, Number and Mobile fields.
4. Press the Save soft key to accept the change.

