




## Panasonic TGP600 Base Unit

### Set-Up

- 1** Attach the **Network Cable** included with the **Base Unit** and plug one end into the network port on the Base Unit. Plug the other end of the cable into the Internet modem, router, switch, hub or RJ-45 network wall jack.
- 2** Firmly plug the **Power Adapter** (AC Adapter) into the base unit. You can utilize the hook on the base to secure it firmly and to prevent it from being accidentally dislodged. The power supply should be connected to an electrical outlet, power bar, surge protector or UPS.
- 3** Once the base unit is connected it will go through a regular connection process which may take up to 10 minutes. Once you see the solid **green** status light, the base is ready and you can proceed in powering up the phones.
- 4** If the status light remains **red** or **amber** after 10 minutes, try plugging the base unit directly into the modem instead of any secondary devices (router, switch, hub etc.).
- 5** Please call Comwave Business Support if the status light does not turn solid **green**.



---

## Important Information

### **Environment**

Keep the phone and base away from heating appliances and devices that generate electrical noise such as fluorescent lamps and motors. These noise sources can interfere with performance.

Do not place the phone or base in rooms where the temperature is less than 0 °C (32 °F) or greater than 40 °C (104 °F).

The range of operation depends on the topography of your office, weather, or usage conditions as signals are transmitted between the base unit and the handset/desk phone by radio waves. If there are obstacles such as walls, noise may interfere with your telephone calls. In particular, high metal shelves or reinforced concrete walls will restrict operating range.

A handset / desk phone may not work when it is too far from the base unit depending on the structure of the building.